

# Hestia 1000 Peninsula Guillotine

## BASIC INSTALL SHEET



Version 2.2 12/03/25


Contents of manual may be updated without notice.

For the latest version of this manual please refer  
to our website: [www.livingfire.com.au](http://www.livingfire.com.au)

**PAUL AGNEW** | **DESIGNS**

# Hestia 1000 PENINSULA GUILLOTINE


## FIREBOX DIMENSIONS WITHOUT EXTERNAL FRAME



**Note:** External trim not included with the unit.

# Hestia 1000 PENINSULA GUILLOTINE

## FIREBOX DIMENSIONS WITH EXTERNAL FRAME



**Note:** External trim not included with the unit.

**HEBEL ENCLOSURE**

25 Min. Clearance

450

PAD 8" Insulated Cowl

Combustible Ceiling

PAD 8" Insulated Ceiling Ring

PAD 8" Insulated Flue\*

37,500mm<sup>2</sup> Air vent

75 Hebel

100 Air Gap

Combustible Wall

75 Hebel

205

75 Hebel

37,500mm<sup>2</sup> Air vent

75.0 Hebel

300


6.0 Cement Sheet

PAUL AGNEW | DESIGNS

# Hestia 1000 PENINSULA GUILLOTINE

## HEBEL ENCLOSURE


### FRONT VIEW



\* Min. Required flue length: 4metres

# Hestia 1000 PENINSULA GUILLOTINE

## HEBEL ENCLOSURE



## HEBEL PANEL DIMENSION

